

Liquid Cleansing Cream

14 1/2 lbs Trihydroxyethylene Amine - Starch

2 lbs Perfume Oil

72 lb Mineral Oil

148 1/2 lbs Water

237 lbs

Directions

Place Trihydroxyamine Starch in a kettle - heat until dissolved - then in another kettle heat mineral oil - just enough so that it will not congeal when it is added to the Trihydroxyamine - Excessive heat should be avoided - but if the mixture should be overheated - allow to stand for a few minutes before mixing in perfume oil, as too much heat will cause slight evaporation of its odour - Then add a small amount of the water which has previously heated to the same temperature as the oily ingredients -

only add enough water until the cream will run smoothly from a paddle and be sure that all lumps are dissolved before adding the balance of the water -

Up to this point the cream should be stirred vigorously and should have a creamy consistency - after this the balance of the water should be added slowly and slow mixing should continue, about 50 to 60 revolutions a minute - will give a silky emulsion
